


## **Assembly Instructions**



## **NO ASSEMBLY REQUIRED**

# **TXD130**

# Yacht Club Dining Side Chair

trexfurniture.com

12/14/2018

## 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

## Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 907-TREX (8739) or email support@trexfurniture.com

## Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

## Cleaning Tips

Keep your Trex Outdoor Furniture looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush: hose down to rinse.



## **Assembly Instructions**



TXL1D81, TXL1R81,

TXL1B81

For Use With Small Plank

Table-PL81

## 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

## Share your space .....

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

## Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 907-TREX (8739) or email support@trexfurniture.com

## Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:


You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

trexfurniture.com





3/8" wrench (not included)

4mm T-handle hex key (included)

## **PARTS**

