

# Assembly Instructions

### 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

### Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

# Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 907-TREX (8739) or email support@trexfurniture.com



# TXL1D81, TXL1R81, TXL1B81 For Use With Small Plank Table-PL81

trexfurniture.com

## Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

#### For a quick clean:


Simply wipe down with soap and water.


#### For a deeper clean:

You'll need:

- »  $^{1\!\!/_3}$  bleach and  $^{2\!\!/_3}$  water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.








В



# Assembly Instructions



## NO ASSEMBLY REQUIRED

# **TXD200** Monterey Bay Dining Arm Chair

#### trexfurniture.com

06/09/2017

### 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

### Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 907-TREX** (8739) or email **support@trexfurniture.com** 

### Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

### Cleaning Tips

Keep your Trex Outdoor Furniture looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:

You'll need:

- »  $\frac{1}{3}$  bleach and  $\frac{2}{3}$  water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.