





## Assembly Instructions

### TXLR2 Leg Kit



### TXFRT3772 Monterey Bay 37" X 72" Counter Table



### TXNCRT3772 Yacht Club 37" X 72" Counter Table

#### 20-Year Warranty

To view our full warranty, please visit  
[trexfurniture.com/warranty](https://trexfurniture.com/warranty)

#### Share your space

We love to see where our furniture  
ends up — snap a pic and share  
it with us on Facebook!  
[facebook.com/trexfurniture](https://facebook.com/trexfurniture)

#### Having Trouble?

If you have questions or concerns regarding  
assembly instructions or missing parts,  
please contact us at **(877) 907-TREX** (8739)  
or email [support@trexfurniture.com](mailto:support@trexfurniture.com)

#### Cleaning Tips

Keep your Trex Outdoor Furniture™  
looking brand new:

##### For a quick clean:

Simply wipe down with soap and water.


##### For a deeper clean:

You'll need:



- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth  
and let it sit on the lumber for a few  
minutes (this will not affect the color).  
Then, loosen any dirt and debris that  
may catch in surface grooves with a  
soft bristle brush; hose down to rinse.


TOOLS



PARTS




1




FRT3772 shown for parts and assembly



2




3



4



TXNCRT3772



TXFRT3772