

## **Assembly Instructions**



TXAD4031
Cape Cod
Adirondack Chair

### 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

## Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

## Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 907-TREX** (8739) or email support@trexfurniture.com

### Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:


You'll need:


- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

trexfurniture.com

# **TOOLS**









7/16" wrench (not included)


# **PARTS**













Flange Nylon Lock Nut HN.25-20FN

Something missing? Call (833) 665-6300



