

# **Assembly Instructions**



TXL1D83, TXL1R83,

TXL1B83

For Use With Small Plank

Table-PL83

### 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

# Share your space .....

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

## Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 907-TREX (8739) or email support@trexfurniture.com

### Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.


#### For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.








3/8" wrench (not included)

4mm T-handle hex key (included)


# **PARTS**









2












# **Assembly Instructions**



#### NO ASSEMBLY REQUIRED

**TXD100** 

Monterey Bay Dining Side Chair

trexfurniture.com

06/09/2017

#### 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

### Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 907-TREX** (8739) or email <a href="mailto:support@trexfurniture.com">support@trexfurniture.com</a>

### Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

### **Cleaning Tips**

Keep your Trex Outdoor Furniture looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:


You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush: hose down to rinse.



# **Assembly Instructions**



#### NO ASSEMBLY REQUIRED

TXD200

Monterey Bay

Dining Arm Chair

trexfurniture.com

06/09/2017

#### 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

### Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 907-TREX (8739) or email support@trexfurniture.com

### Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

### Cleaning Tips

Keep your Trex Outdoor Furniture looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.