


# **Assembly Instructions**



TXDT3872-T15

Parsons 38" x 72" Dining Table

### 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

## Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

## Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 907-TREX** (8739) or email support@trexfurniture.com

## Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

trexfurniture.com







4mm T-handle 4mm hex for drill hex key (included)


(included)

(Screw Gun Recommended) (Not Included)


# **PARTS**








NOTE - Ensure thru holes in legs line up with pilot holes in aprons.












# **Assembly Instructions**



TXADD200, 201, 202 Cape Cod Adirondack Chair

### 20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

### Share your space .....

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

## Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 907-TREX (8739) or email support@trexfurniture.com

### Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

trexfurniture.com





4mm T-handle hex key (included)

4mm hex key (included)

# **PARTS**

