




## Assembly Instructions



**TXL1D85, TXL1R85,  
TXL1B85  
For Use With Large Plank  
Table-PL85**

### 20-Year Warranty

To view our full warranty, please visit  
[trexfurniture.com/warranty](http://trexfurniture.com/warranty)

### Share your space

We love to see where our furniture  
ends up — snap a pic and share  
it with us on Facebook!  
[facebook.com/trexfurniture](https://facebook.com/trexfurniture)

### Having Trouble?

If you have questions or concerns regarding  
assembly instructions or missing parts,  
please contact us at **(877) 907-TREX** (8739)  
or email [support@trexfurniture.com](mailto:support@trexfurniture.com)

### Cleaning Tips

Keep your Trex Outdoor Furniture™  
looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.


#### For a deeper clean:

You'll need:


- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth  
and let it sit on the lumber for a few  
minutes (this will not affect the color).  
Then, loosen any dirt and debris that  
may catch in surface grooves with a  
soft bristle brush; hose down to rinse.

TOOLS




3/8" wrench  
(not included)




4mm T-handle  
hex key (included)

PARTS




**A** x 8




3" Screw — HHW14X3

**B** x 8




3" Screw — H.27X3


1



2




Removable  
table plug





## Assembly Instructions



### **TXTLD230** Cape Cod Dining Arm Chair

#### ..... **20-Year Warranty** .....

To view our full warranty, please visit  
[trexfurniture.com/warranty](http://trexfurniture.com/warranty)

#### ..... **Share your space** .....

We love to see where our furniture  
ends up — snap a pic and share  
it with us on Facebook!  
[facebook.com/trexfurniture](https://facebook.com/trexfurniture)

#### ..... **Having Trouble?** .....

If you have questions or concerns regarding  
assembly instructions or missing parts,  
please contact us at **(877) 907-TREX** (8739)  
or email [support@trexfurniture.com](mailto:support@trexfurniture.com)

#### ..... **Cleaning Tips** .....

Keep your Trex Outdoor Furniture™  
looking brand new:

##### **For a quick clean:**

Simply wipe down with soap and water.


##### **For a deeper clean:**

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush


Wipe on solution with your cloth  
and let it sit on the lumber for a few  
minutes (this will not affect the color).  
Then, loosen any dirt and debris that  
may catch in surface grooves with a  
soft bristle brush; hose down to rinse.

## TOOLS




3/8" wrench  
(not included)

## PARTS




**A** x 2



2.5" Screw — HHW14X2.5


**B** x 2




Cap Dowel Screw — HD.25X2+P11420

1


Twist dowel screw into arm until  
finger-tight, remove protective cap




2




3




4



5



Repeat Steps 1 Thru 4  
On Opposite Side



**Trex**<sup>®</sup>  
Outdoor Furniture™