


Assembly Instructions

TXLB Leg Kit



TXRBT236

Monterey Bay Round 36" Bar Table

TXRBT248

Monterey Bay Round 48" Bar Table



TXNCBT37 Yacht Club 37"

Bar Table

TXNCBT44
Yacht Club 44"
Bar Table

20-Year Warranty

To view our full warranty, please visit trexfurniture.com/warranty

Share your space

We love to see where our furniture ends up — snap a pic and share it with us on Facebook! facebook.com/trexfurniture

Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 907-TREX** (8739) or email support@trexfurniture.com

Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

For a quick clean:

Simply wipe down with soap and water.

For a deeper clean:


You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

trexfurniture.com

TOOLS








4mm T-handle hex key (included)


3/8" wrench (not included)


PARTS














4



